


ASSEMBLY INSTRUCTIONS


Step 1

Lay YardStash flat and face-up on ground near desired location (the recommended location for your YardStash is on a flat area and against a wall or fence).




Step 2

Insert one elbow pole down through each sleeve on right side and left side with elbow towards top. Do not connect the right clips to pole.




Step 3

Insert long "v" pole through top front sleeve.




Step 4

Connect the left end of the "v" pole to the left elbow pole. Make sure to connect the side with no clips first.




Step 5

Connect the right end of the "v" pole to the right elbow pole. Do not connect clips to pole.




Step 6

Insert bottom caps of elbow poles into eyelets on bottom corners (use eyelets closest to YardStash).



Step 7

Attach right side clips to elbow pole.




Step 8 Turn over Yardstash and repeat steps 2-7 for back side.

ASSEMBLY INSTRUCTIONS-continued


Step 9

Insert ends of poles with blue stickers into eyelets located on left and right sides of front sleeves and connect each pole to opposite eyelet on back sleeves.



Step 10

Slide pole with yellow sticker through the two nylon loops located on the middle of the roof and connect pole to the front and bottom back eyelets. Connect two remaining poles with red stickers to eyelets located on the right and left hand side of the roof. To fully stabilize and straighten your YardStash after assembly, pull bottom of corner poles out and away from middle and unzip product to release air.



Use stakes to secure YardStash to ground and/or insert screws through remaining eyelets on back side to fasten YardStash to fence or wall.

⚠ Warning ⚠

Do not use YardStash as a tent, shelter or play structure for humans or animals. Death by suffocation is possible if YardStash is used as a tent, shelter or play structure for humans or animals. Do not allow children to play near or in YardStash. Never place a stove, campfire, or other flame source in or near your YardStash. Anchor your YardStash properly at all times to reduce the risk of loss or damage to YardStash or contents inside of YardStash. Carefully consider the possibility of falling rocks or tree limbs, lightning strikes, flash floods, strong winds, and other hazards when choosing your YardStash location to reduce the risk of loss and/or injury. YardStash Solutions LLC or any reseller cannot be held responsible for loss or damage to personal belongings or equipment as a result of theft or adverse weather conditions. YardStash Solutions LLC or any reseller cannot be held responsible for any personal injury caused by misuse of product.